

**THRU BOLT HOLES**  
 DRILL ON BOTH SIDES  
 1/2" DIA.

**TRIM CLEARANCE HOLE**  
 DRILL ON INSIDE  
 2 1/8" DIA. (SEE NOTE 1)

**SPINDLE HOLE**  
 DRILL ON OUTSIDE  
 7/8" DIA.

**ALIGNMENT PIN HOLES**  
 DRILL ON OUTSIDE  
 3/8" DIA. 2 PLACES

**THRU BOLT HOLES**  
 DRILL ON BOTH SIDES  
 1/2" DIA. (SEE NOTE 1)

**NOTE:**  
 1. DRILL THE 1/2 DIA HOLE BEFORE THE 2 1/8 DIA HOLE

USE OTHER SIDE OF THIS TEMPLATE FOR MARKING OPPOSITE SIDE OF DOOR.

USE OTHER SIDE OF THIS  
TEMPLATE FOR MARKING  
OPPOSITE SIDE OF DOOR.

**THRU BOLT HOLES**  
DRILL ON BOTH SIDES  
1/2" DIA.

**NOTE:**  
1. DRILL THE 1/2 DIA  
HOLE BEFORE THE  
2 1/8 DIA HOLE


**TRIM CLEARANCE HOLE**  
DRILL ON INSIDE  
2 1/8" DIA. (SEE NOTE 1)

**SPINDLE HOLE**  
DRILL ON OUTSIDE  
7/8" DIA.

**HORIZONTAL  $\phi$**   
**OF LEVER**  
MATCH WITH THE HORIZONTAL  
LINE DRAWN ON THE DOOR.


**ALIGNMENT PIN HOLES**  
DRILL ON OUTSIDE  
3/8" DIA. 2 PLACES

**THRU BOLT HOLES**  
DRILL ON BOTH SIDES  
1/2" DIA. (SEE NOTE 1)




LOW EDGE  
FLAT (NO BEVEL)  
HIGH EDGE  
CUT LINE

RECESS TO FIT  
STRIKE PLATE AND  
STRIKE BOX



PILOT HOLE FOR #12  
SCREW (2 PLCS)



**STRIKE**  
1" DRILL X  
1-1/8" DEEP  
3-21/32" HIGH  
TRIM CORNERS

3-3/8" CUT-OUT  
ON LEFT OR RIGHT  
FOR CURVED STRIKE LIP

3/16"  
CORRECT LOCATION  
FOR LOWER EDGE  
OF ASA STRIKE LIP  
ABOVE HORIZONTAL  
 $\phi$  OF LEVER.

HIGH EDGE  
FLAT (NO BEVEL)  
LOW EDGE  
CUT LINE